

Service Manual

Sample order

Item :ALC-6A 6kg /0.2g

Units Switch

- 1) Press "Zero" key to re-zero the scale
- 2) Press "Zero" + "1" + "1" ,select unit g
- 3) Press "Zero" + "1" + "2" ,select unit lb
- 4) Press "Zero" + "1" + "3" ,select unit kg

External Calibration (the unit is g)

- 1) First remove all objects from weighing tray, make sure the balance show zero .
- 2) Press "Zero" key ,the second window will show "Centr " and press " 2 " key before it disappear, it will show 5000, put on the 5kg weight on the pan. when the scale is stable , the calibration is complete.

Internal Calibration (the unit is g)

- 1) First remove all objects from weighing tray, make sure the balance show zero .
- 2) Press "Zero" + "SMPL " + "M+ " at the same time
- 3) The weighing window twinkle " CAL 2500" , put on the 2500g weight on the pan , when the third window stable indicator appears ,
- 4) Press " Unit W.T. " key ,the weighing window twinkle " CAL 5000 " , put on the 5 kg weight , the third window stable indicator appears ,
- 5) Press "Unit W.T. " for test to return to zero.

Set Capacity and Division (set 6kg/0.1g) unit is g

- 1) First remove all objects from weighing tray, make sure the balance show zero .
- 2) Press “Zero”+ “M+” at the same time, the second window will show “SELECT”, input the password 200805 by numeric keys .
- 3) Press ”MC” key, the weighing window show “ 0 “ , input ‘6000’ (**capacity setting**) ,
- 4) press “Q’TY PST” key , and then press “MC “ key ,the weighing window show “ 0 “ , input “ 0.1 “ (**division setting**) ,
- 5) pres “QTY PST” key , and then press “ MC “ key to input “ 5000 “(**calibration weight**, usually its value is equal to the 2/3 capacity),
- 6) press “ QTY PST “ key to self-test the scale and return to zero.

Recovery the factory setting

Press “Zero “ + “CE “ key at the same time , the second window show ‘ r ES ‘ , press “ 1 “ key to re-zero.